



- 1.) Shorten cable to the wanted length
- 2.) Thread the cable in the holder
- 3.) Dismantle cable
- 4.) Place the contacts correct (see images)
- 5.) Solder cables - pay attention to correct polarity (see images - PIN 1)
- 6.) Fix the contacts with superglue or similar
- 7.) Fix the solder area with hot glue or similar

